




135537 Assembly Instructions






Hardware Components



This bag contains small parts that present a choking hazard for children under 3 years of age. These parts are for adult assembly only and should be permanently affixed to the furniture. Any unused parts should be discarded properly.




1.





2.




Save for Step 9




3.




Remove Panel and
save for steps 5 and 6



Save items for
later Steps




4.






5.

Panel from Step 3
(Unfinished Side)


Slide Panel up to the front
and rest on the clips



6.




7.



Slide Fireplace unit
up to the front

8.



9.

