


ASSEMBLY INSTRUCTIONS FOR:


HEADBOARD

SIGNATURE DESIGN BY **ASHLEY®**

PART # 142204 (05/21/26)



HARDWARE



This bag contains small parts that present a choking hazard for children under 3 years of age. These parts are for adult assembly only and should be permanently affixed to the furniture. Any unused parts should be discarded properly.


Esta bolsa contiene piezas pequeñas que presentan un peligro de asfixia, para niños menores de 3 años. Estas piezas son para adultos, montaje solamente y debe fijarse permanentemente a la muebles. Las piezas no utilizadas deben desecharse correctamente.

Ce sac contient de petites pièces qui présentent un risque d'étouffement pour les enfants de moins de 3 ans. Ces pièces sont pour adultes montage uniquement et doit être fixé de façon permanente au meubles. Toutes les pièces inutilisées doivent être jetées correctement.

Deze tas bevat kleine onderdelen die verstikkingsgevaar opleveren voor kinderen onder de 3 jaar. Deze onderdelen zijn voor volwassen montage alleen en moet permanent worden bevestigd aan de meubilair. Alle ongebruikte onderdelen moeten op de juiste manier worden weggegooid.

HARDWARE AND
COMPONENTS NEEDED
ON THIS PAGE:

G5 30MM JOINT CONT.



H24 ALLEN WRENCH



Remove screws if present

Retire los tornillos si están presentes

Retirez les vis si elles sont présentes

Verwijder eventuele schroeven

If present, save for step 2

Si está presente, guarde para el paso 2

Si présent, enregistrez pour l'étape 2

Indien aanwezig, bewaar voor stap 2

