



143421 Assembly Instructions







Hardware Components


This bag contains small parts that present a choking hazard for children under 3 years of age. These parts are for adult assembly only and should be permanently affixed to the furniture. Any unused parts should be discarded properly.



Step 1



Step 2



Step 3

