


Read all instructions BEFORE assembly and USE of product.
KEEP INSTRUCTIONS FOR FUTURE USE.

newton[®]

Compact Travel Crib & Play Yard, Model 5101

Instruction Manual

Scan below
for quick video
assembly guide:



Any questions? Please feel free to contact us at (800)686-3986
or info@newtonbaby.com. We're always happy to help.

MAN5101-20250521

WARNING

Failure to follow these warnings and the instructions could result in serious injury or death. Keep instructions for future use. Assemble product according to the instructions for ANY use mode.

SUFFOCATION HAZARD


Babies have suffocated:

- on pillows, comforters, and extra padding
- in gaps between product sides and a wrong-size mattress or extra padding
- NEVER add soft bedding, padding or an extra mattress.
- ONLY use the mattress as described in the warnings on this product.
- The product, including side rails, must be fully erected prior to use.
- Make sure latches are secure.
- Make sure the bottom hook and loop strips are securely attached.
- To reduce the risk of SIDS, pediatricians recommend healthy infants be placed on their back to sleep, unless otherwise advised by your physician.
- Discontinue use of the product when child is able to climb out or reaches the height of 35 in. (890 mm).
- Always provide the supervision necessary for the continued safety of your child. When used for playing, never leave child unattended.
- Strings can cause strangulation! Never place items with a string around a child's neck such as hood strings or pacifier cords. Never suspend strings over product or attach strings to toys.
- Never place product near a window where cords from blinds or drapes can strangle a child.
- Child can become entrapped and die when improvised netting or covers are placed on top of product. Never add such items to confine child in product.
- When child is able to pull to standing position, remove bumper pads, large toys, and other objects that could serve as steps for climbing out.
- Never use plastic shipping bags or other plastic film as mattress covers not sold and intended for that purpose. They can cause suffocation.
- Never use a water mattress with this product.
- Never use this product if there are any loose or missing fasteners, loose joints, broken parts, or torn mesh/fabric. Check before assembly and periodically during use.
- Contact Newton Baby, Inc. for replacement parts. Never substitute parts.

Parts List

Check that all parts listed below are included in your package.
If there are any missing parts, contact Newton Baby for replacements before use.



Part	Part Name	Quantity
A	Travel Crib & Play Yard	1
B	Mattress Pad	1
C	Hook and Loop Strips	1
D	Plastic Feet	1
E	Fitted Sheet	1
F	Carry Bag	1



To Assemble the Travel Crib



Step 1

Unzip the travel bag and remove the Travel Crib. Unfasten the hook and loop strips on the back of the pad to open the mattress pad flat.




Step 2

Lay the crib upside down and undo the buckle that holds the Travel Crib together. Open the four legs by pulling them upwards.




Step 3

Assemble the plastic feet by placing them into the open ends of the leg tubes. Push on the feet until they click into place.




Step 4

Turn the travel crib over. Click the top frame into place by pulling out on the short sides first. Then pull out on the two longer sides until they click into place.




Step 5

Place the mattress pad inside the Travel Crib so it is resting securely on the bottom. Ensure the mattress pad is flat and covers the entire base of the Travel Crib. Pull the four hook and loop strips through the bottom slots in all four corners and attach to the underside of the bottom fabric. Ensure the hook and loops strips are securely connected.



Step 6

To use the side door, unclip the zipper buckle and unzip until fully opened. When closing the side door, always make sure the zipper is completely closed and the zipper buckle is attached to the base clip.




⚠ WARNING:

This travel crib is ready for use only when the top frame locking mechanisms are engaged, the feet are clicked into place and the mattress pad is securely attached to the bottom fabric.

To Fold and Store the Travel Crib


Step 1

Release the four hook and loop strips on the underside of the Travel Crib and pull the mattress pad up to remove it from the bottom surface. Press the buttons on the long sides of the top frame, as indicated by the gray arrows, to unlock the frame.




Step 2

Pull the long sides out slightly and then press the frame inward towards the middle. Press the shorter sides inwards as needed until the top frame folds compactly.




Step 3

Turn the Travel Crib over. Press the spring button on each leg towards the feet and fold the legs inwards until flat. Clip the strap around the bottom of the Travel Crib to hold it in place.




Step 4

Wrap the mattress pad tightly around the Travel Crib, then slide the plastic hooks through the loops on the backside of the mattress pad to close. Place the Travel Crib in the carry bag and zip closed.




Carry bag can be used with the handle or with the backpack straps. When not in use, the backpack straps can be zippered inside the side pocket. For added convenience, the Travel Crib can be placed on top of wheeled luggage by sliding the open panel over the luggage handle.



To Convert Carry Bag to Backpack

Step 1

Unzip the pocket and remove the back straps. Clip the ends of the straps to the loops on the bag to convert the bag into a backpack.



Reminder


Never leave a child unattended. Always supervise your child.

Travel Crib Fabric Care and Use

Spot cleaning is recommended for most messes. Simply wipe play yard fabric with a damp cloth.


To Remove Cover

Unzip cover on all four sides and remove completely from frame. Unclick feet from each leg and remove the cover.



To Disassemble Feet

Turn the Travel Crib over. To disassemble the plastic feet. Press the button by the foot and pull foot out of leg. Repeat for all four feet.



Fabric Cover Care Instructions

Machine wash cold on gentle cycle and hang dry. Do not tumble dry. Do not bleach. Do not dry clean. Check the condition of the fabric Travel Crib for any possible damage after each wash. In case of damage, do not use Travel Crib. Zip cover around Travel Crib and reattach to frame.

IMPORTANT! Please ensure that all four feet are properly placed into the legs and the top fabric panel is securely zipped around all sides of the frame.


Pad Care Instructions

Remove fitted sheet, unzip pad to separate cover and core.


Pad cover: Fully zip cover closed before washing and drying. Machine wash cold, alone, use delicate cycle. Tumble dry thoroughly on low. Do not bleach. Do not dry clean. Replace if damaged.

Pad core: Hand rinse cold (in shower or tub). Use mild detergent. Shake excess water from core then air or fan dry. Avoid heat or direct sun.

Fitted sheet: Wash before first use. Machine wash cold with like colors. Do not bleach. Tumble dry low. Do not iron. Do not dry clean.



Protective Zipper Pull Pocket



newton®

382 NE 191st Street
Miami, FL 33179

www.newtonbaby.com
info@newtonbaby.com
800-686-3986