

## ASSEMBLY INSTRUCTION SHEET FOR D442-25

### IMPORTANT SAFETY NOTICE: READ CAREFULLY BEFORE BEGINNING ASSEMBLY!

- \* Always use proper tools.
- \* Follow the assembly steps in order. Do not skip any steps.
- \* Carefully review the list of parts. If parts are missing, contact the retailer from which you purchased the product to obtain any missing parts. DO NOT USE SUBSTITUTE PARTS.

- \* Periodically check to ensure that all connectors (bolts, screws, etc.) are tight.
- \* Keep the instructions for future reference.
- \* Do not stand on tables, including but not limited to, end tables, coffee tables, and dinner tables, as tables are not meant to support the weight of a person.



NOTE: ASHLEY FURNITURE INDUSTRIES, INC. DISCLAIMS ANY LIABILITY FOR DAMAGES OR INJURIES WHICH MAY OCCUR DUE TO FAILURE TO PROPERLY FOLLOW ASSEMBLY INSTRUCTIONS, PROPERLY ASSEMBLE THE PRODUCT, OR PROPERLY USE THE PRODUCT.

### CHECK TO SEE THAT THE FOLLOWING PARTS ARE IN THE HARDWARE PACK!



BOX WRENCH - 1 PC



NUT - 8 PCS




WASHER - 8 PCS




LOCK WASHER - 8 PCS

①

1. Set the table top down on a smooth protective surface.
2. Remove the legs from the pack.




②




3. Place a leg into a corner of the table top so the bolts in the leg are through the holes on the corner block.

③



④

1. Carefully set the table upright.



1. Using a wrench tighten a washer, lock washer and bolt into each hole.
2. Repeat for remaining legs.