













CROSLEY
FURNITURE

Storage Cabinet






CF3121



PART LIST

A 	B 	C 	D2 	E 
Top Panel 1 PC	Left Panel 1 PC	Right Panel 1 PC	Cross Rail 1 PC	Bottom Panel 1 PC
F 	G2 	H2 	I2 	J2 
Drawer Front Panel 1 PC	Drawer Left Panel 1 PC	Drawer Right Panel 1 PC	Drawer Back Panel 1 PC	Drawer Bottom Panel 1 PC
K 	L 	M2 	N2 	
Left Door Panel 1 PC	Right Door Panel 1 PC	Back Panel 1 PC	Adjustable Shelf 1 PC	

HARDWARE LIST

#1  Ø1/4"*25mm Bolt 10 PCS (Extra 1)	#2  Ø1/4"*11mm Spring Washer 10 PCS (Extra 1)	#3  Ø1/4"*13mm Flat Washer 10 PCS (Extra 1)	#4  4mm*90 Allen Wrench 1 PC	#5  Ø8*30mm Wood Dowel 12 PCS (Extra 1)
#6  Magnet 1 PC	#7  6*3*15mm Round Head Screw 2 PCS (Extra 1)	#8  Door Hinge 4 PCS	#9  7*3.5*15mm Screw 24 PCS (Extra 1)	#10  Handle 3 PCS
#11  5/32"*19mm Long Round Head Bolt 4 PCS (Extra 1)	#12  5/32"*15mm Short Round Head Bolt 2 PCS (Extra 1)	#13  Shelf Holder 4 PCS (Extra 1)	#14  8*3*12mm Short Screw 16 PCS (Extra 1)	#15  Safety Strap Kit 1 SET
#16  8*4*25 Long Screw 8 PCS (Extra 1)				

ADDITIONAL TOOLS (Not Provided)


Note: It is not recommended to use power tools during assembly.




Phillips Head Screwdriver

Note: Wood dowels are intended for alignment. Additional clearance between wood dowel and pre-drilled hole is intentional for ease of assembly.

Please adjust hinges as needed for proper door alignment.




Step 1. Attach magnet (part #6) to cross rail (part D2) using round head screws (part #7) and phillips head screwdriver. Attach handle (part #10) to drawer front panel (part F) using short round head bolts (part #12) and phillips head screwdriver.




- | | | |
|-----|---|-----|
| #6 |  | x 1 |
| #7 |  | x 2 |
| #10 |  | x 1 |
| #12 |  | x 2 |


Step 2. Attach door hinges (part #8) to left door panel (part K) and right door panel (part L) using screws (part #9) and phillips head screwdriver. Attach handles (part #10) to left door panel (part K) and right door panel (part L) using long round head bolts (part #11) and phillips head screwdriver.




Step 3. Attach drawer panels (parts G2 & H2) to drawer front panel (part F) using long screws (part #16) and phillips head screwdriver. Slide drawer bottom panel (part J2) into the grooves of assembled unit (parts F, G2 & H2). Attach drawer back panel (part I2) to assembled unit (parts G2, H2 & J2) using long screws (part #16) and phillips head screwdriver.




Step 4. Attach cross rail (part D2) to left panel (part B) and right panel (part C) using wood dowels (part #5), bolts (part #1), spring washers (part #2), flat washers (part #3) and allen wrench (part #4).




Step 5. Attach top panel (part A) to assembled unit (parts B & C) using wood dowels (part #5), bolts (part #1), spring washers (part #2), flat washers (part #3) and allen wrench (part #4).



Step 6. Attach bottom panel (part E) to assembled unit (parts B & C) using wood dowels (part #5), bolts (part #1), spring washers (part #2), flat washers (part #3) and allen wrench (part #4).







Step 7. Carefully turn unit upright. Attach back panel (part M2) to assembled unit (parts A, B, C & E) using short screws (part #14) and phillips head screwdriver.



Step 8. Place shelf holders (part #13) into desired position and slide adjustable shelf (part N2) and assembled drawer into place.

Note: To release trigger disconnect levers push one side up and the other down.

Move the sliders to the front end of rail before sliding the drawer into place.





#13  x 4

Step 9. Attach door panels (parts K & L) to panels (parts B & C) using screws (part #9) and phillips head screwdriver.

NOTE: It is important to adjust levelers once fully assembled and upright. Extend adjustable leveler until it's firmly in contact with the floor. If relocating, adjust leveler as needed until it's firmly in contact with the floor in new location.

Important: Safety strap kit (part #15) must be installed to prevent tipping, damage and/or injury.




#15	A	B	C	D	E
					
Safety Strap Kit 1 SET	Wall Anchor 1 PC	Bracket 2 PCS	Short Screw 1 PC 8*3*15mm	Long Screw 1 PC 8*4*35mm	Safety Wall Strap 1 PC

SAFETY WALL STRAP INSTALLATION

Note: It is highly recommended to install this safety strap kit to prevent tipping, damage and/or injury.

1. Insert short screw (C) and safety wall strap (E) through bracket (B) and attach to top panel (part A) using phillips head screwdriver.
2. Drill a 11/32" hole where you want to secure the unit. The drilled hole will be at the same height as the hole in top panel (part A) where bracket (B) is attached. Tap wall anchor (A) into the hole.
3. Insert long screw (D) and safety wall strap (E) through bracket (B) into wall anchor (A) using phillips head screwdriver.

Note: This item is not intended for clothing storage use.



⚠ WARNING




Children have died from furniture tipover. To reduce the risk of furniture tipover:

- ALWAYS install tipover restraint provided.
- NEVER put a TV on this product.
- NEVER allow children to stand, climb or hang on drawers, doors, or shelves.
- NEVER open more than one drawer at a time.
- Place heaviest items in the lowest drawers.

This is a permanent label. Do not remove!