


Silos Floor Lamp

Model # 3146-01



1. Screw pole(B) clockwise into base(A) to tighten.
2. Screw pole(C) clockwise into pole(B) to tighten.
3. Screw pole(D) clockwise into pole(C) to tighten.
4. Screw socket part(E) clockwise into pole(D) to tighten.
5. Attach the harp(F) on the socket.
6. Set the shade(G) on the harp and tighten clockwise with the finial(H).

GENERAL PRODUCT INFORMATION:

This product is suitable for dry locations only.



IMPORTANT SAFETY INSTRUCTIONS:

This portable lamp has a polarized plug (one blade is wider than the other) as a feature to reduce the risk of electric shock. This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless plug can be fully inserted. **DO NOT ALTER THE PLUG.**

BULB TYPE: (1) 150 watt maximum incandescent or 18 watt maximum equivalent LED bulb. (not included)