INK+IVY

# WALKER COFFEE TABLE

*Assembly instructions:*

**PARTS LIST**

| No. | DESCRIPTION | IMAGE | Q'TY |
|---|---|---|---|
| P1 | LEG FRAME 1 |  | 1 |
| P2 | LEG FRAME 2 |  | 1 |
| P3 | LEG FRAME 3 |  | 1 |
| P4 | TABLE TOP |  | 1 |


**HARDWARE LIST**

| No. | DESCRIPTION | IMAGE | Q'TY |
|---|---|---|---|
| H1 | BOLT (Ø1/4" x 15 MM) |  | 12 |
| H2 | SPRING WASHER (Ø1/4") |  | 12 |
| H3 | FLAT WASHER (Ø1/4") |  | 12 |
| H4 | METAL BRACKET |  | 2 |
| H5 | WOODEN DOWEL |  | 4 |
| H6 | ALLEN KEY |  | 1 |


**NOTE**: PO # is located underneath/ at the back side of each item. Please be prepared to provide this # should any claim be necessary.

**CAUTION**: Item is heavy. Assembly should be performed by two people.

1





2



* UPSIDE DOWN FRAME

3




ASSEMBLY COMPLETED