




ASSEMBLY INSTRUCTIONS

TV Stand

EEI-6598 / V1.02.02.26

modway



Questions? Contact us!

609.256.9000

cs@modway.com

Welcome.

Let's get started.

Before you begin, here are some things to keep in mind:

Assembly will take most people **about 60 minutes**. Consider having a friend help you!

Only use hand tools to assemble this item. Do not use power tools. Do not tighten bolts or screws completely until all hardware is lined up and inserted into the holes.

Read through all of the instructions before starting. Make sure you have all parts and components before discarding any packing materials.

Do not over-tighten screws and bolts to avoid stripping the hardware or cracking the item.

Assemble your item on a flat, carpeted area, with plenty of space to work. This will prevent damage and scratches to your floors or the item while you're assembling the product.

Keep all components and packaging out of reach of children or animals to avoid risk of choking or suffocation.


Care instructions are listed in the last step of this manual.

WAIT!


Missing parts or hardware? Need assistance?
Contact us before returning your item.
We're here to help!



HARDWARE INCLUDED IN THE BOX:

A		Cam Lock Ø15mm	x26
B		Cam Bolt Ø7.5 x 32mm	x32
C		Cam Cover Ø17mm	x10
D		Plastic Dowel M6 x 30mm	x60
E		Screw M6 x 13 mm	x8
F		Screw 10 x 33.5mm	x18
G		Screw 6 x 8mm	x16
H		Backply Stopper	x22
I		Screw 4 x 19mm	x22
J		Door Hinge	x4
K		Drawer Rail	x2
L		Cam Lock Ø12 mm	x6
M		Push To Open	x4
N		Cam Cover Ø15 mm	x4
O		Shelf Pin	x8

WHAT YOU NEED:




Phillips Head Screwdriver

FURNITURE COMPONENTS INCLUDED IN THE BOX:

Page 3 of 15

All parts are numbered with a sticker according to this list.




1	Top Board	x1	11	Bottom Rear Support	x1
2	Bottom board	x1	12	Bottom Left Support	x2
3	Left Board	x1	13	Bottom Right Support	x2
4	Right Board	x1	14	Front Drawer	x2
5	Divider Left Board	x1	15	Rear Drawer	x2
6	Divider Right Board	x1	16	Left Drawer	x2
7	Drawer Support	x1	17	Right Drawer	x2
8	Adjustable Shelf	x2	18	Bottom Support Drawer	x2
9	Backboard	x1	19	Bottom Drawer	x2
10	Bottom Front Support	x1	20	Door	x2

STEP 01

1.1 Insert Plastic Dowel (D) into Left Board (3) and Right Board (4) as shown.

1.2 Insert and screw Cam Bolt (B) into Top Board (1) as shown.



HARDWARE

- B** Cam Bolt Ø7.5 x 32 mm x8
- D** Plastic Dowel M6 x 30 mm x8

COMPONENTS

- 1** Top Board x1
- 3** Left Board x1
- 4** Right Board x1


TOOLS

- 1** Phillips Head Screwdriver x1

STEP 02

1.1 Attach Push To Open (M) to Bottom Board (2) using Screw (G) as shown.

1.2 Rotate the panel, insert and screw Cam Bolt (B) into Bottom Board (2) as shown.



HARDWARE

- B** Cam Bolt Ø7.5 x 32 mm x12
- G** Screw M6 x 8 mm x2
- M** Push To Open x1

COMPONENTS

- 2** Bottom Board x1

TOOLS

- 1** Phillips Head Screwdriver x1

3.1 Insert and screw Cam Bolt (B) into Divider Left Board (5) as shown.

3.2 Attach Drawer Rail (K) to Divider Left Board (5) using Screw (G).

3.3 Rotate the panel, insert Plastic Dowel (D) into Divider Left Board (5) as shown.

3.4 Attach Push To Open (M) to Divider Left Board (5) using Screw (G) as shown.

3.5 Insert Plastic Dowel (D) into Drawer Support (7) as shown.

3.6 Attach Push To Open (M) to Drawer Support (7) using Screw (G) as shown.

HARDWARE


B	Cam Bolt Ø7.5 x 32 mm	x1
D	Plastic Dowel M6 x 30 mm	x6
G	Screw M6 x 8 mm	x8
K	Drawer Rail	x2
M	Push To open	x2

COMPONENTS

5	Divider Left Board	x1
7	Drawer Support	x1

TOOLS

1	Phillips Head Screwdriver	x1
----------	---------------------------	----



4.1 Insert and screw Cam Bolt (B) into Divider Right Board (6) as shown.

4.2 Attach Drawer Rail (K) to Divider Right Board (6) using Screw (G).

4.3 Rotate the panel, insert Plastic Dowel (D) into Divider Right Board (6) as shown.

4.4 Attach Push To Open (M) to Divider Right Board (6) using Screw (G) as shown.

HARDWARE


B	Cam Bolt Ø7.5 x 32 mm	x1
D	Plastic Dowel M6 x 30 mm	x4
G	Screw M6 x 8 mm	x6
K	Drawer Rail	x2
M	Push To open	x1

COMPONENTS

6	Divider Right Board	x1
----------	---------------------	----


TOOLS

1	Phillips Head Screwdriver	x1
----------	---------------------------	----



5.1 Insert and screw Cam Bolt (B) into Bottom Front Support (10) as shown.

5.2 Insert Plastic Dowel (D) into Bottom Front Support (10), Bottom Rear Support (11), Bottom Left Support (12) and Bottom Right Support (13) as shown.



HARDWARE

- B** Cam Bolt Ø7.5 x 32 mm x4
- D** Plastic Dowel M6 x 30 mm x22

COMPONENTS

- 10** Bottom Front Support x1
- 11** Bottom Rear Support x1
- 12** Bottom Left Support x2
- 13** Bottom Right Support x2

TOOLS


- 1** Phillips Head Screwdriver x1

STEP 06

6.1 Attach Bottom Front Support (10) to Bottom Left Support (12) and Bottom Right Support (13) as shown.

6.2 Insert Cam Lock (A) to the assembled unit, then tighten it using Phillips Head Screwdriver.

6.3 Attach Bottom Rear Support (11) to Bottom Left Support (12) and Bottom Right Support (13) using Screw (F).



HARDWARE

- A** Cam Lock Ø15 mm x4
- F** Screw M10 x 33.5 mm x4

COMPONENTS


- 10** Bottom Front Support x1
- 11** Bottom Rear Support x1
- 12** Bottom Left Support x2
- 13** Bottom Right Support x2

TOOLS

- 1** Phillips Head Screwdriver x1

7.1 Attach Divider Left Board (5) and Divider Right Board (6) to Drawer Support (7) as shown.

7.2 Insert Cam Lock (A) to the assembled unit, then tighten it using Phillips Head Screwdriver.



HARDWARE

- A** Cam Lock Ø15 mm x2
- C** Cam Cover Ø17 mm x2

COMPONENTS

- 5** Divider Left Board x1
- 6** Divider Right Board x1
- 7** Drawer Support x1

TOOLS

- 1** Phillips Head Screwdriver x1

STEP 08

8.1 Attach Left Board (3), Right Board (4) and assembled divider to Bottom Board (2) using Screw (F) as shown.

HARDWARE


- F** Screw M10 x 33.5 mm x8

COMPONENTS

- 2** Bottom Board x1
- 3** Left Board x1
- 4** Right Board x1
- 5** Divider Left Board x1
- 6** Divider Right Board x1


TOOLS

- 1** Phillips Head Screwdriver x1



9.1 Attach assembled bottom support to the assembled unit as shown.

9.2 Insert Cam Lock (A) to the assembled unit, then tighten it using Phillips Head Screwdriver.



HARDWARE

A Cam Lock Ø15 mm x12

COMPONENTS

2 Bottom Board x1

10 Bottom Front Support x1

11 Bottom Rear Support x1

12 Bottom Left Support x2

13 Bottom Right Support x2

TOOLS

1 Phillips Head Screwdriver x1

STEP 10

10.1 Attach Bottom Board (9) to the assembled unit as shown.


COMPONENTS

2 Bottom Board x1

3 Left Board x1


4 Right Board x1

9 Backboard x1



11.1 Attach Top Board (1) to the assembled unit as shown.

11.2 Insert Cam Lock (A) to the assembled unit, then tighten it using Phillips Head Screwdriver.



HARDWARE

- A** Cam Lock Ø15 mm x8
- C** Cam Cover Ø17 mm x8

COMPONENTS


- 1** Top Board x1
- 3** Left Board x1
- 4** Right Board x1
- 5** Divider Left Board x1
- 6** Divider Right Board x1

TOOLS

- 1** Phillips Head Screwdriver x1

STEP 12

12.1 Install Backply Stopper (H) on the assembled unit using Screw (I).



HARDWARE

- H** Backply Stopper x14
- I** Screw M4 x 19 mm x14

COMPONENTS


- 1** Top Board x1
- 2** Bottom Board x1
- 3** Left Board x1
- 4** Right Board x1
- 9** Backboard x1

TOOLS

- 1** Phillips Head Screwdriver x1

13.1 Insert Shelf Pin (O) into the assembled unit as shown.

13.2 Insert Adjustable Shelf (8) into the assembled unit as shown.



HARDWARE

○ Shelf Pin M7 x 16.5 mm x8

COMPONENTS

③ Left Board x1

④ Right Board x1

⑤ Divider Left Board x1


⑥ Divider Right Board x1

⑧ Adjustable Shelf x2

STEP 14

14.1 Insert and screw Cam Bolt (B) into Front Drawer (14) as shown.

14.2 Insert Plastic Dowel (D) into Rear Drawer (15), Left Drawer (16), Right Drawer (17) and Bottom Support Drawer (18) as shown.



HARDWARE

Ⓑ Cam Bolt Ø7.5 x 32 mm x6

Ⓓ Plastic Dowel M6 x 30 mm x20

COMPONENTS

⑭ Front Drawer x2

⑮ Rear Drawer x2

⑯ Left Drawer x2

⑰ Right Drawer x2


⑱ Bottom Support Drawer x2

TOOLS

① Phillips Head Screwdriver x1

15.1 Attach Left Drawer (16), Right Drawer (17) and Bottom Support Drawer (18) to Rear Drawer (15) using Screw (F).

15.2 Insert Bottom Drawer (19) to assembled drawer as shown.



HARDWARE

F Screw M10 x 33.5 mm x6

COMPONENTS

15 Rear Drawer x2

16 Left Drawer x2

17 Right Drawer x2

18 Bottom Support Drawer x2

19 Bottom Drawer x2

TOOLS


1 Phillips Head Screwdriver x1

STEP 16

16.1 Attach Front Drawer (14) to assembled drawer as shown.

16.2 Insert Cam Lock (A) to the assembled unit, then tighten it using Phillips Head Screwdriver.

16.3 Install Backply Stopper (H) on the assembled drawer using Screw (I).



HARDWARE

H Backply Stopper x8

I Screw M4 x 19 mm x8

L Cam Lock Ø12 mm x6

N Cam Cover Ø15 mm x4

COMPONENTS

14 Front Drawer x2

16 Left Drawer x2


17 Right Drawer x2

18 Bottom Support Drawer x2

TOOLS

1 Phillips Head Screwdriver x1

17.1 Attach Drawer Rail (K) to assembled drawer using Screw (E).



HARDWARE

- E** Screw M6 x 13 mm x8
- K** Drawer Rail x2

COMPONENTS

- 16** Left Drawer x2
- 17** Right Drawer x2

TOOLS

- 1** Phillips Head Screwdriver x1



STEP 18

18.1 Insert all the drawers to the assembled unit as shown.


18.2 Adjust Push To Open (M) until it's fixed.

COMPONENTS

- 5** Divider Left Board x1
- 6** Divider Right Board x1
- 7** Drawer Support x1
- 14** Front Drawer x2



19.1 Install Door Hinge (J) to Door (20) as shown.



HARDWARE

J Door Hinge x4

COMPONENTS

20 Door x2



TOOLS

1 Phillips Head Screwdriver x1

STEP 20

20.1 Attach Door (20) to the assembled unit as shown.
Adjust the door hinge until it's fixed.

20.2 Adjust Push To Open (M) until it's fixed.



COMPONENTS




3 Left Board x1

4 Right Board x1

20 Door x2

TOOLS

1 Phillips Head Screwdriver x1




Great job!

TV Stand assembly is complete.

CARING FOR YOUR ITEM

- Indoor use only.
- Not contract grade.
- Clean using a non-abrasive cloth and a mild cleaner.
- Never use harsh chemicals, as they could damage the finish or integrity of the item.



CONNECT WITH US!

Tag us @modway_furniture and #modway for a chance to be featured.

modway



Questions? Contact us!

609.256.9000
cs@modway.com